

Descaling **LCD Ring Display**

Descaling is as important as changing the oil in your car every 3,000 miles. It is a process that eliminates mineral build up inside your boiler and ensures the machine's longevity. For normal household use we recommend descaling at least once every 3 months, depending on the volume of use and hardness of your local water supply.

There are many good descaling agents on the market today including Saeco's own product: Part number 524000, 3 packets, \$4.90 plus \$5.90 shipping and handling. Any descaling product used with Saeco machines should be citric based. Do not use vinegar or lemon juice as this will cause damage to the machine.

Tip: To ensure that the descaling solution completely dissolves, mix 1 packet of descaling solution with 1 cup of water, stir until powder is completely dissolved and pour into the water tank. Then add additional 3 cups of water.

WARNINGS

Do not swallow. Avoid eye contact. Wash hands after use.
Do not expose to heat. Keep out of reach of children.
This product is non-toxic, biodegradable and odorless.

Step by Step

For use with Primea Ring.

1. Start with the machine turned off.
2. Remove the Aqua Prima water filter from the tank and fill with the descaling solution. (1 packet of Saeco descaling solution to 4 cups of water.)
3. Turn the machine on and navigate to the descaling menu and press the brew button to begin.
4. The machine will dispense the solution at pre-established intervals until the water tank is empty.
5. Remove the water tank and rinse thoroughly. Refill with fresh drinking water and replace on machine.
6. Rinse the machine circuits by pressing the brew button. (You may need to refill the water tank during this rinse cycle.)
7. When the rinse cycle is complete, press the brew button and then menu to exit the programming mode.

For questions or concerns please contact Saeco Customer Service at 800.933.7876 or email at support@saeco-usa.com.